


S/W 510R COIL RACK

FOR USE WITH COIL, SIZES FROM NO.1 THROUGH NO.5 PHASE HEADS.FROM SMALL MOTORS TO 50 HP.



PART LIST SW510R		
ITEM	DESCRIPTION	QUANTITY
1	Base Assembly	1
2	Main Assembly	1
3	Column	1
4	Coil Holder Support	1
5	Coil Holders	3
6	Thumb Screw	3
7	Thumb Screw	1
8		