



PART LIST SW 519

ITEM	PART#	DESCRIPTION	QUANTITY
1		Base	1
2		Main Column Assembly	1
3		Screws	2
4		Support Guide Assembly	1
5		Wire Guide	1
6			

SW 519  
WIRE GUIDE